Serial No: RFI-SAR-RP89460JD03A V3.0

Issue Date: 07 September 2012

## Appendix 6. System Check

Prior to the assessment, the system was verified in the flat region of the phantom. A 900 MHz dipole was used. A forward power of 250 mW was applied to the dipole and the system was verified to a tolerance of  $\pm 5\%$  for the 900 MHz dipole.

The applicable verification normalised to 1 Watt.

Date: 08/08/2012	
Validation Dipole and Serial Number: D900V2; SN:	124

Simulant	Frequency (MHz)	Room Temp	Liquid Temp	Parameters	Target Value	Measured Value	Deviation (%)	Limit (%)		
		24.0.90	24 N °C 23 5 °C	24.0 °C 23.		ε <sub>r</sub>	41.50	40.98	-1.24	5.00
Head	900				900 24.0 °C 23.5 °C	23 5 °C	23.5 °C	σ	0.97	0.97
neau 900	24.0 0	23.5 C	1g SAR	11.00	10.96	-0.36	5.00			
						10g SAR	7.01	7.12	1.57	5.00

Date: 10/08/2012

Validation Dipole and Serial Number: D900V2; SN: 124

Simulant	Frequency (MHz)	Room Temp	Liquid Temp	Parameters	Target Value	Measured Value	Deviation (%)	Limit (%)			
		24.0.9C 23.1.9C	<b>σ</b> 0.9'	22 1 00	ε <sub>r</sub>	41.50	41.36	-0.35	5.00		
Hoad	Head 900 24.0 °C				0.97	0.94	-2.60	5.00			
Head		23.1 C	1g SAR	11.00	11.16	1.45	5.00				
							10g SAR	7.01	7.32	4.42	5.00

Date: 08/08/2012

Validation Dipole and Serial Number: D900V2; SN: 124

Simulant	Frequency (MHz)	Room Temp	Liquid Temp	Parameters	Target Value	Measured Value	Deviation (%)	Limit (%)					
		24.0 °C	24.0.00	24 D °C 23 4 °C		ε <sub>r</sub>	55.00	53.16	-3.34	5.00			
Body	900				24 0 °€	24 0 °C 23 4	24.0 °C 23.4 °C	24 0 °€	23 4 %	23 / 90	σ	1.05	1.04
Бойу	900		20.4 0	20.4 0	1g SAR	11.10	11.24	1.26	5.00				
							10g SAR	7.14	7.36	3.08	5.00		

Page: 66 of 70 RFI Global Services Ltd.

Serial No: RFI-SAR-RP89460JD03A V3.0

Issue Date: 07 September 2012

## **Appendix 7. Simulated Tissues**

The body mixture consists of de-ionised water, Polysorbate 20 and salt. Visual inspection is made to ensure air bubbles are not trapped during the mixing process. The mixture is calibrated to obtain proper dielectric constant (permittivity) and conductivity of the tissue.

	Frequency
ingredient	835/850/900 MHz Head
De-Ionized Water	52.87
Polysorbate 20 (Tween 20)	46.10
Salt	1.03

Ingredient	Frequency
	835/850/900 MHz Body
De-Ionized Water	71.30
Polysorbate 20 (Tween 20)	28.00
Salt	0.70

Page: 67 of 70 RFI Global Services Ltd.

Test Report Version 3.0 Serial No: RFI-SAR-RP89460JD03A V3.0

Issue Date: 07 September 2012

## **Appendix 8. DASY4 System Details**

## A.8.1. DASY4 SAR Measurement System

RFI Global Services Ltd. SAR measurement facility utilises the Dosimetric Assessment System (DASY™) manufactured by Schmid & Partner Engineering AG (SPEAG™) of Zurich, Switzerland. The DASY4 system is comprised of the robot controller, computer, near-field probe, probe alignment sensor, and the SAM phantom containing brain or muscle equivalent material. The robot is a six-axis industrial robot performing precise movements to position the probe to the location (points) of maximum electromagnetic field (EMF). A cell controller system contains the power supply, robot controller; teach pendant (Joystick), and remote control. This is used to drive the robot motors. The Staubli robot is connected to the cell controller to allow software manipulation of the robot. The data acquisition electronics (DAE) performs signal amplification, signal multiplexing, AD-conversion, offset measurements, mechanical surface detection, collision detection etc. The DAE is connected to the Electro-optical coupler (EOC). The EOC performs the conversion from the optical into digital electric signal of the DAE and transfers data to the PC plug-in card. The DAE3 utilises a highly sensitive electrometer-grade preamplifier with auto-zeroing, a channel and gain-switching mulitplexer, a fast 16bit AD-converter and a command decoder and control logic unit. Transmission to the PC-card is accomplished through an optical downlink for data and status information and an optical uplink for commands and clock lines. The mechanical probe-mounting device includes two different sensor systems for frontal and sidewise probe contacts. They are also used for mechanical surface detection and probe collision detection. The robot uses its own controller with a built in VME-bus computer.

Page: 68 of 70 RFI Global Services Ltd.

A.8.2. DASY4 SAR System Specification Robot System	ations				
Positioner:	Stäubli Unimation Corp. Robot Model: RX90L				
Repeatability:	0.025 mm				
No. of Axis:	6				
Serial Number:	F00/SD89A1/A/01				
Reach:	1185 mm				
Payload:	3.5 kg				
Control Unit:	CS7				
Programming Language:	V+				
Data Acquisition Electronic (DAE) System					
Serial Number:	DAE3 SN:432				
PC Controller					
PC:	Dell Precision 340				
Operating System:	Windows 2000				
Data Card:	DASY4 Measurement Server				
Serial Number:	1080				
Data Converter					
Features:	Signal Amplifier, multiplexer, A/D converted and control logic.				
Software:	DASY4 Software				
Connecting Lines:	Optical downlink for data and status info. Optical uplink for commands and clock.				
PC Interface Card					
Function:	24 bit (64 MHz) DSP for real time processing Link to				

robot.

Serial No: RFI-SAR-RP89460JD03A V3.0

DAE3 16 nit A/D converter for surface detection system serial link to robot direct emergency stop output for

Issue Date: 07 September 2012

Page: 69 of 70 RFI Global Services Ltd.

DASY4 SAR System Specifications (Continued)				
E-Field Probe				
Model:	EX3DV4			
Serial No:	3814			
Construction:	Triangular core			
Frequency:	10 MHz to >6 GHz			
Linearity:	±0.2 dB (30 MHz to 6 GHz)			
Probe Length (mm):	330			
Probe Diameter (mm):	12			
Tip Length (mm):	20			
Tip Diameter (mm):	2.5			
Sensor X Offset (mm):	1			
Sensor Y Offset (mm):	1			
Sensor Z Offset (mm):	1			
E- Phantom				
Phantom:	SAM Phantom			
Shell Material:	Fibreglass			
Thickness:	2.0 ±0.1 mm			

Issue Date: 07 September 2012

Page: 70 of 70 RFI Global Services Ltd.